

Coating Prefinished Floors

Tie Tack can also be used as a recoat adhesion system for all types of polyurethane finished hardwood floors.

1. Sweep or vacuum floor to remove loose dirt.
2. Spray Tie Tack undiluted directly on floor at a rate of 2,000 square feet per gallon. For large areas a string mop can be used to apply Tie Tack. Abrade floor while it is wet with a standard speed buffer and a maroon pad with 180 grit-sanding strips. The floor should be damp enough to be slightly wet after abrading.
3. Tack the floor with undiluted Tie Tack and cotton towels to remove any residue.
4. Allow floor to dry and abrade again using maroon pad and 180 grit-sanding strips.
5. Tack the floor again with undiluted Tie Tack and cotton towels to remove any residue.
6. Within two hours after the floor has dried topcoat with Poloplaz waterbase or oil base finish system.



WWW.POLOPLAZ.COM

800.421.7319 | 501.985.1172 | 501.985.1359 fax | info@poloplaz.com

POLOPLAZ | 1 PARADISE PARK ROAD | JACKSONVILLE, ARKANSAS 72076

